

■ Main Menu

```
- [Main] - Advanced - Security - Boot - Exit -

System Time: [xx:xx:xx]
System Date: [xx/xx/xxxx]
LAN MAC Address: xx-xx-xx-xx-xx-xx
Boot Display Device: [Both]

▼ Primary Master [xxxxxMB]
Secondary Master Installed CD/DVD

System Memory: xxx KB
Extended Memory: xxxxxx KB
CPU Type: xxxxxxxxxxxx
CPU Speed: xxxx MHz
BIOS Version: x.xx-xxxx-xxxx
```

Main Menu	BIOS default	BIOS value
SystemTime		XX:XX:XX[] [00] 23/[] [00] 59/[] [00] 59[]
System Date		XX/XX/XXXX[] [01] 12/[] [01] 31/[] XXXX[]
LAN MAC Address		XX-XX-XX-XX-XX-XX
Boot Display Device	Both	LCD/CRT
Primary Master		XXXXXMB
Secondary Master		Installed CD/DVD
System Memory		XXX KB
Extended Memory		XXXXXX KB
CPU Type		XXXXXXXXXX
CPU Speed		XXXX MHz
BIOS Version		X.XX-XXXX-XXXX

[illegible]

■ IDE Primary Master Information [HDD] [] [] [] [] []

```

-[Main]-
----- Primary Master [xxxxxMB]-----

Type:                                [Auto]

Total Sectors:                       xxxxxxxxx
Maximum Capacity:                    xxxxxMB

Multi-Sector Transfers:              [16 Sectors]
LBA Mode Control:                    [Enabled]
32 Bit I/O:                          [Disabled]
Transfer Mode:                       [Fast PIO 4 / DMA 2]
Ultra DMA Mode:                      [Mode 5]

```

Primary Master Information		
	BIOS default	BIOS value
Type	Auto	Auto
Total Sectors		□ □ □ □ □ □ □ □ □
Maximum Capacity		□ □ □ □ □ □ □ □ □
Multi-Sector Transfers		
LBA Mode Control		
32 Bit I/O		□ □ □ □ □ □ □ □ □
Transfer Mode		
Ultra DMA Mode		

[illegible]

■ Advanced Menu □ □ □ □ □ □ □

- Main - [Advanced] - Security - Boot - Exit -

```

NunLock:                                [ LockOff]

Embedded Share Memory:                  [ 8MB]
Quiet Boot:                             [Enabled]
Screen Expansion:                        [Disabled]
Legacy USB Support:                      [Enabled]
USB 2.0:                                 [Enabled]
PXE PROM:                               [Disabled]
Wake on LAN from S5:                    [Enabled]

```

▼ I/O Device Configuration

Advanced Menu

Advanced Menu	BIOS default	BIOS value
NumLock	LockOff	LockOn
Embedded Share Memory	8MB	1MB/ 4MB/ 16MB/ 32MB
Quiet Boot	Enabled	Disabled
Screen Expansion	Disabled	Enabled
Legacy USB Support	Enabled	Disabled
USB 2.0	Enabled	Disabled
PXE OPROM	Disabled	Enabled
Wake on LAN from S5	Enabled	Disabled

NumLock	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	NumLock	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Embedded Share Memory	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Quiet Boot	<input type="checkbox"/>	(Disabled)														
Screen Expansion	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Legacy USB Support	<input type="checkbox"/>	Windows <input type="checkbox"/> USB <input type="checkbox"/>														
USB 2.0	<input type="checkbox"/>	USB2.0 <input type="checkbox"/>														
PXE OPROM	<input type="checkbox"/>	LAN <input type="checkbox"/>														
Wake on LAN from S5	<input type="checkbox"/>	S5 <input type="checkbox"/> Wake on LAN <input type="checkbox"/>														

Onboard Devices Configuration Menu

```

- [ Advanced ] -
----- I/O Device Configuration -----

```

Serial Port A:	[Auto]
Parallel Port:	[Auto]
Mode:	[Bi-directional]

Onboard Devices Configuration Menu

	BIOS default	BIOS value
Serial Port	Auto	Enabled/ Disabled
Base I/ O Address	3F8	2F8/ 3E8/ 2E8
Interrupt	IRQ 4	IRQ 3
Parallel Port	Auto	Enabled/ Disabled
Mode	Bi-directional	ECP
Base I/ O Address	378	278/ 3BC
Interrupt	IRQ 7	IRQ 5
DMA channel	DMA 3	DMA 1

```

Serial Port  ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
               ☐ Enabled ☐ ☐ ☐
               ☐ Disabled ☐ ☐ ☐ ☐
               ☐ Auto BIOS ☐ OS ☐ ☐ ☐ ☐ ☐ ☐ ☐
Base I/O Address ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
                  ☐ ☐ : Serial Port: ☐ Enabled ☐ ☐ ☐ ☐ ☐ ☐
Interrupt ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
              ☐ ☐ : Serial Port: ☐ Enabled ☐ ☐ ☐ ☐ ☐ ☐
Parallel Port ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
                 ☐ Enabled ☐ ☐ ☐ ☐
                 ☐ Disabled ☐ ☐ ☐ ☐
                 ☐ Auto BIOS ☐ OS ☐ ☐ ☐ ☐ ☐ ☐
Mode ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
        ☐ ☐ : Parallel Port: ☐ Disabled ☐ ☐ ☐ ☐ ☐ ☐
Base I/O Address ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
                  ☐ ☐ : Parallel Port: ☐ Enabled ☐ ☐ ☐ ☐ ☐ ☐
Interrupt ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
              ☐ ☐ : Parallel Port: ☐ Enabled ☐ ☐ ☐ ☐ ☐ ☐
DMA channel ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐ ☐
               ☐ ☐ : Parallel Port: ☐ ECPC ☐ ☐ ☐ ☐ ☐ ☐

```

Security Menu () () () () () () () ()

- Main - Advanced - [Security] - Boot - Exit -

Supervisor Password Is: Clear
User Password Is: Clear
Set Supervisor Password: [Enter]
Set User Password: [Enter]

Set Primary Hard Disk Password: [Enter]
HDD Password Status: Clear
Password on boot: [Disabled]

-I/O Security
Modem: [Enabled]
LAN: [Enabled]
1394/ CARDBUS: [Enabled]
USB: [Enabled]
Wireless LAN: [Enabled]

Security Menu

	BIOS default	BIOS value
Supervisor Password Is		Clear / Set
User Password Is		Clear / Set
Set Supervisor Password		Enter
Set User Password		Enter
Set Primary Hard Disk Password		Enter
HDD Password Status		Clear / Set / Locked
Password on boot	Disabled	Enabled
Modem	Enabled	Disabled
LAN	Enabled	Disabled
1394/ CARDBUS	Enabled	Disabled
USB	Enabled	Disabled
Wireless LAN	Enabled	Disabled

Supervisor Password Is () () () () () () () () () () () () () () () ()
Set User Password () () () () () () () () () () () () () () () ()
Set Supervisor Password () () () () () () () () () () () () () () () ()
Set User Password () () () () () () () () () () () () () () () ()
[Supervisor Password] () () () () () () () () () () () () () () () ()
[User Password] () () () () () () () () () () () () () () () ()
System Time/ System Date/ Boot Display Device/ Screen Expansion/ Set User Password
/ Exit Saving Changes/ Exit Discarding Changes/ Discard Changes/ Save Changes
Set Primary Hard Disk Password () () () () () () () () () () () () () () () ()
HDD Password Status () () () () () () () () () () () () () () () ()
Password on boot () () () () () () () () () () () () () () () ()
[Supervisor Password] () () () () () () () () () () () () () () () ()
Password on boot () () () () () () () () () () () () () () () ()
Modem () () () () () () () () () () () () () () () ()
LAN () () () () () () () () () () () () () () () ()
1394/ CARDBUS () () () () () () () () () () () () () () () ()
USB () () () () () () () () () () () () () () () ()
Wireless LAN () () () () () () () () () () () () () () () ()

Boot Menu () () () () () () () ()

- Main - Advanced - Security - [Boot] - Exit -

F12 Multi Boot Menu: [Enabled]

Boot Sequence:
Hard Drive
CD-ROM Drive
Removable Devices

Boot Menu

	BIOS default	BIOS value
F12 Multi Boot Menu	Enabled	Disabled

F12 Multi Boot Menu () () () () () () () () () () () () () () () ()
Boot Sequence () () () () () () () () () () () () () () () ()

■ Exit Menu () () () () ()

```
- Main - Advanced - Security - Boot - [Exit] -
```

Exit Saving Changes
Exit Discarding Changes
Load Setup Defaults
Discard Changes
Save Changes

Exit Saving Changes

Exit Discarding Changes

Load Setup Defaults

Discard Changes

Save Changes